W.T.T. 2013 /81 VICRAIL W.T.T. 2013/81

Office of Chief Operations Manager
Metrol, Batman Avenue
Phone 2142

21st July, 1981.

METROPOLITAN DISTRICT WORKING TIME-TABLE PARTS I AND II

Commencing Monday 10th August, 1981 the Frankston-Stony Point Bus service will be amended as follows:

A Reprint pages, (103B) Mondays to Fridays and (209A) Sunday, are attached. Saturday alterations plus connection alterations are listed below.

PART I - (MONDAYS TO FRIDAYS)

PAGE

91 - 4318 amend note to read, connects with bus from Hastings.
- 4708 insert, connects with bus from Crib Point.
- 4324 delete, connects with bus from Crib Point.

95 - 4342 delete, connects with bus from Stony Point.

PART II (SATURDAYS)

PAGE

76B - 09 10 down bus, amend Crib Point timing to read 09 48.

PART II (SUNDAYS)

PAGE

202 - 4321 insert, connects with bus to Stony Point
- 4323 delete, connects with bus to Stony Point

208 - 4334 insert connects with bus from Stony Point.
- 4336 delete, connects with bus from Stony Point.

All concerned to note and arrange.

R.T. BARDEN
CHIEF OPERATIONS MANAGER
PER:-

FRANKSTON - STONY POINT

MONDAYS TO FRIDAYS

CONNECTING ELECTRIC TRAIN								
Flinders Street	dep	06 08	06 22	08 07	10 00	11 00	11 53	
Frankston	arr	07 11	07 28	09 10	11 03	12 03	13 03	
DOWN		BUS	BUS	2 BUSES	BUS	BUS	BUS	
Frankston (Railway Station)	dep	07 16	07 33	09 15	11 10	12 10	13 10	
Frankston (State College)		B	B	B	B	B	B	
Baxter (Cnr Flinders Rd & Tooradin Rd)		07 24	07 41	09 23	11 18	12 18	13 18	
Somerville (Flinders Rd-Station Entrance)		07 29	07 46	09 28	11 23	12 23	13 23	
Tyabb (Crn Flinders Rd & Mornington Rd)		07 34	07 51	09 33	11 28	12 28	13 28	
Hastings (King St-Comfort Station)		07 41	08 00	09 40	11 35	12 35	13 35	
Hastings West (Hodgins Rd-Estate Entrance)		...	...	...	...	...	...	
Bittern (Station Entrance)		07 45A	...	09 44	11 39A	12 39A	13 39A	
Stopping Place 15 (Crn Stony Point Rd & Disney St)		07 51	...	09 50	11 45	12 45	13 45	
Crib Point (Station Entrance)		07 58	...	09 53	11 52	12 52	13 52	
Stony Point (Station)	arr	...	...	10 00	...	...	...	

CONNECTING ELECTRIC TRAIN								
Flinders Street	dep	12 53	13 53	14 53	16 33	17 04	17 26	
Frankston	arr	14 03	15 03	16 03	17 36	18 06	18 35	
DOWN		BUS	BUS	2 BUSES	BUS	BUS	BUS	
Frankston (Railway Station)	dep	14 10	15 10	16 10	17 40	18 10	18 40	
Frankston (State College)		B	B	B	B	B	B	
Baxter (Crn Flinders Rd & Tooradin Rd)		14 18	15 18	16 18	17 48	18 18	18 48	
Somerville (Flinders Rd-Station Entrance)		14 23	15 23	16 23	17 53	18 23	18 53	
Tyabb (Crn Flinders Rd & Mornington Rd)		14 28	15 28	16 28	17 58	18 28	18 58	
Hastings (King St-Comfort Station)		14 35	15 35	16 35	18 05	18 35	19 05	
Hastings West (Hodgins Rd-Estate Entrance)		14 43A	...	1 BUS	...	...	...	
Bittern (Station Entrance)		14 52A	...	16 39	...	18 39A	19 09A	
Stopping Place 15 (Crn Stony Point Rd. & Disney St)		14 58	...	16 45	...	18 45	19 15	
Crib Point (Station Entrance)		15 05	...	16 48	...	18 52	19 22	
Stony Point (Station)	arr	...	...	16 55	...			

UP		BUS	BUS	BUS	BUS	BUS	BUS	BUS
Stony Point (Station)	dep	...	...	...	...	10 00	10 07	...
Crib Point (Station Entrance)		...	06 32	...	08 10	10 03	10 10	12 10
Stopping Place 15 (Crn Stony Point Rd & Disney St)		...	06 34	...	08 12	10 05	10 12	12 12
Bittern (Station Entrance)		...	06 38	...	08 16	10 09	10 16	12 16
Hastings West (Hodgins Rd-Estate Entrance)		...	...	...	...	10 17	...	...
						2 BUSES		
Hastings (King St-Comfort Station)		06 28	06 45	08 05	08 23	10 23		12 23
Tyabb (Crn Flinders Rd & Mornington Rd)		06 34	06 51	08 11	08 29	10 29		12 29
Somerville (Flinders Rd-Station Entrance)		06 40	06 57	08 17	08 35	10 35		12 35
Baxter (Crn Flinders Rd & Tooradin Rd)		06 46	07 03	08 23	08 41	10 41		12 41
Frankston (State College)		A	A	A	A	A		A
Frankston (Railway Station)	arr	07 00	07 17	08 35	08 55	10 55		12 55

CONNECTING ELECTRIC TRAIN								
Frankston	dep	07 05	07 22	08 40	09 00	11 00		13 00
Flinders Street	arr	08 06	08 27	09 44	10 04	12 01		14 01

UP		BUS	BUS	BUS	BUS	BUS	BUS	BUS
Stony Point (Station)	dep	...	...	...	...	...	17 10	...
Crib Point (Station Entrance)		13 10	14 10	15 05	...	...	17 13	...
Stopping Place 15 (Crn Stony Point Rd & Disney St)		13 12	14 12	15 07	...	...	17 15	...
Bittern (Station Entrance)		13 16	14 16	15 11	...	...	17 19	...
Hastings West (Hodgins Rd-Estate Entrance)		...	...	...	...	...	...	...
Hastings (King St-Comfort Station)		13 23	14 23	15 18	15 38	16 35	17 26	18 07
Tyabb (Crn Flinders Rd & Mornington Rd)		13 29	14 29	15 24	15 44	16 40	17 32	18 12
Somerville (Flinders Rd-Station Entrance)		13 35	14 35	15 30	15 50	16 45	17 38	18 17
Baxter (Crn Flinders Rd & Tooradin Rd)		13 41	14 41	15 36	15 56	16 50	17 44	18 22
Frankston (State College)		A	A	A	A	A	A	A
Frankston (Railway Station)	arr	13 55	14 55	15 50	16 08	17 00	17 57	18 35

CONNECTING ELECTRIC TRAIN								
Frankston	dep	14 00	15 00	15 56	16 17	17 07	18 01	18 40
Flinders Street	arr	15 01	16 01	16 58	17 19	18 08	19 02	19 41

A - Stop only to set down B - Stop only to pick up

For full service between Flinders Street and Frankston see pages 73 - 103

W.T.T. 2013 /81

FRANKSTON - STONY POINT

SUNDAYS

CONNECTING ELECTRIC TRAIN				
Flinders Street	dep	08 46	15 26	18 46
Frankston	arr	09 52	16 32	19 52
DOWN		2 BUSES	2 BUSES	2 BUSES
Frankston (Railway Station)	dep	10 00	16 40	20 00
Leawarra (Bloom St - adjacent Station)		10 06	16 46	20 06
Baxter (Station Entrance)		10 11	16 51	20 11
Somerville (Flinders Rd - Station Entrance)		10 17	16 57	20 17
Tyabb (Crn Flinders Rd & Mornington Rd)		10 22	17 02	20 22
Hastings (King St - Comfort Station)		10 29	17 09	20 29
Bittern (Station Entrance)		10 33	17 13A	20 33A
Stopping Place 15 (Crn Stony Point Rd & Disney St)		10 39	17 19	20 39
Crib Point (Station Entrance)		10 42	17 22	20 42
Stony Point (Station)	arr	10 50	17 30	20 50
UP		2 BUSES	2 BUSES	
Stony Point (Station	dep	11 10	17 45	
Crib Point (Station Entrance)		11 13	17 48	
Stopping Place 15 (Crn Stony Point Rd & Disney St)		11 15	17 50	
Bittern (Station Entrance)		11 19	17 54	
Hastings (King St - Comfort Station)		11 26	18 01	
Tyabb (Crn Flinders Rd & Mornington Rd)		11 32	18 07	
Somerville (Flinders Rd - Station Entrance)		11 38	18 12	
Baxter (Station Entrance)		11 44	18 19	
Leawarra (Bloom St - adjacent Station)		11 54	18 29	
Frankston (Railway Station)	arr	12 05	18 40	
CONNECTING ELECTRIC TRAIN				
Frankston	dep	12 10	18 50	
Flinders Street	arr	13 09	19 54	

For full service between Flinders Street and Frankston see pages 201 - 209.